

Di Grandi Dimensioni Machine

Regular Cleaning & Rinsing Procedure

Machine

- a) Open the coffee machine by inserting the metal key
- b) Place an empty cup underneath the coffee dispenser
- c) Put the green color key in the slot which is located on the upright door (extreme left side)
- d) Coffee machine will restart and will say "Ready" on the LCD screen
- e) On the backside of the door press and hold the "washing" red color button for 3 secs. Machine will make a "beep" sound and rinsing process will start in all the three hoppers
- f) Discard the dirty water in the cup after rinsing process is complete
- g) Place the same cup underneath the coffee dispenser
- h) Repeat step e) & f) (rinse process) for 2 more times, total of 3 times
- i) After the 3rd rinse discard the dirty water and cup
- j) Wipe the machine door from inside and outside including the dispenser and safety door area
- k) Remove the drip tray and rinse it under warm water. Make sure the drip tray is clean before putting it back in the machine
- I) Remove the green key from the machine
- m) Close and lock the door

Machine Base

- a) Open the bottom coffee machine with the black & silver key
- b) Check the used coffee ground container. If half full remove the plastic bag filled with used coffee ground and replace the container with new empty plastic bag. Important: container needs to be right under the waste coffee ground shoot.
- c) Discard the dirty water in the black container, clean the container and place it back in the same location. <u>Important: the pipe outlet needs to be in the black container</u>. And do not touch the round white solid block hanging. This block has to hang over the black container
- d) Wipe the machine door from inside and outside
- e) Close and lock the door